TECHNICAL BULLETIN

PRODUCT: BUDERUS 4000 CONTROL

BURNER FEED WIRING DIAGRAMS:

Attached is an updated wiring diagram showing the first and second stage burner cable connections from the Buderus 4000 control unit to the Wieland plugs.

This diagram shows the colour coding of the wires.



Fig. 1: First Stage burner wiring

The second stage connections from the 4-way Wieland plug to the burner are black with a number identification.



Fig. 2: Second Stage burner wiring

Page 1 of 1

Whilst it is always our intention to fully assist, it is essential to recognise that all information given by the company in response to an enquiry of any nature is provided in good faith and based upon the information provided with the enquiry. We recommend that advice should always be checked with your installer or contract partner. Consequently, the company cannot be held responsible for any liability relating to the use or repetition of such information or part thereof. In addition, whilst making every reasonable effort to monitor the performance and quality of our supply, installation and service network, we do not accept responsibility for the workmanship or operation of any third party company that the company may have promoted either in conversation, e-mail or other communication. Similarly, the views and opinions expressed in communication with individuals within the company may not reflect that of the business as a whole.



Buderus, Cotswold Way, Warndon, Worcester WR4 9SW Technical Services Tel: 0844 892 4224, Fax: 01905 753130, email: Technical.Enquiries@uk.bosch.com